

Poulan PRO[®]

Portable Electric Generator

Service Manual
Model: PPG6000



Contents

Chapter 1 General Information.....	3-7
General Description of Generator.....	3
Safety Information.....	4
Model Parameters.....	5
Maintenance and Adjusting Data.....	5-7
Chapter 2 Maintenance of the Generator Set.....	8
2.1 Maintenance of Starting System.....	8-10
2.2 Maintenance of Lubrication System.....	10-11
2.3 Maintenance of Inlet System.....	12-13
2.4 Maintenance of Fuel System.....	13-14
2.5 Maintenance of Exhaust System.....	14-15
2.6 Maintenance of Ignition System.....	16-17
2.7 Maintenance of Generator.....	18-20
2.8 Maintenance of Cylinder Head and Valve.....	20-24
2.9 Maintenance of Crankcase, Crankshaft and Camshaft.....	25-28
2.10 Maintenance of Connecting Rod, Piston and Cylinder.....	29-31
2.11 Electrical System	32
2.12 Wiring Diagram.....	33
Chapter 3 Trouble Shooting.....	34
3.1 General.....	34
3.2 Hard Starting.....	35
3.3 Ignition System.....	35
3.4 Generator Power Flow Chart.....	36
3.5 Electrical Troubleshooting Stator.....	37
3.6 General Troubleshooting.....	38
Chapter 4 Exploded View and Bill of Materials (BOM).....	39
4.1 Exploded Views.....	39-42
4.2 Bill of Materials (BOM).....	42-50

Chapter 1 General Information

PPG6000 Generator is equipped with a single cylinder, 4 stroke, forced air-cooled, OHV 25° slant, internal combustion engine. It is equipped with an electronic ignition system and is tuned to meet all EPA and California Emissions Requirements.




Figure 1.1

General Description:

1. Gas Tank
2. Choke
3. Fuel Shut Off
4. Pull Starter
5. Oil Dipstick
6. 120 Volt Outlet
7. Ground
8. Circuit Breaker
9. On Off Switch
10. Gas Cap
11. Gas Tank
12. Valve Cover
13. Air Filter
14. Frame
15. Muffler

Safety Information:



This symbol is known as the safety alert symbol and points out safety instructions that can lead to injury or death.



Attention:

Please read and understand this manual and the safety information prior to starting the Generator.

⚠ DANGER

Danger: Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

⚠ WARNING

Warning: Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

⚠ CAUTION

Caution: Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.



SAFETY INSTRUCTIONS

This generator is designed to supply electrical power. Please read and understand all of the safety instructions and warning labels associated with this generator.

- 1) Do not operate indoors.
- 2) Generator must be on a flat stable surface. Surface slope not to exceed 4 degrees.
- 3) Operate in a well-lit and ventilated area.
- 4) Do not operate in moist or wet conditions including the surrounding ground.
- 5) The generator should be a minimum of 3 feet away from all combustible materials and should not be used around hazardous materials.
- 6) Operating at a gas or natural gas filling station is forbidden.
- 7) Do not touch muffler or cylinder during or after operation. They are hot.
- 8) No smoking when filling the gas tank.
- 9) Do not overflow gas tank. Fill the tank to 1 inch below the top neck to allow for gas expansion. Ensure the ventilation hole in the gas cap is not plugged with foreign matter such as dirt or leaves.
- 10) The engine should be shut off for at least 2 minutes before adding gas or oil.
- 11) Do not open the gas tank or oil reservoir while the engine is running.
- 12) Be mindful of the danger, warning and caution labels on the generator.
- 13) Keep away from children. Children should be kept at a minimum of 6 feet away from the generator at all times.
- 14) In a normal situation the generator should be shut off using the instructions found on the front panel label.

Specifications

PPG6000

Dimension/Weight

Engine

Model	PPG6000
LxHxW - Inches	26.8x20x21.3
Net Weight, Box Incl.	185lb
Gross Weight, Full of Fuel	220lb

Model	OHV13H
Engine Type	4-stroke, overhead valve, cylinder tilt 25°
Cylinder discharge capacity	389 cc
Bore x Stroke	88x64 mm
Cooling System	Forced Air Cooling
Ignition System	Transistor Magnet Ignition
Spark Plug	NGK, BP6ES
Engine Oil Volume	1.1Qt
Fuel Volume)	6.6 Gallon
Compression Ratio	8.0:1

Model		PPG6000
	Rated Voltage	120V / 240V
	Rated Frequency	60HZ
	Rated Current	27.2A
	Rated Output	6.0KW
	Max Output	6.3KW

Generator

Maintenance and Adjusting Data

Tolerance Parameters			
Parts	Item	Standard	Extreme Max/Min
	Max Speed	3750 \pm 150, No Load	-
	Cylinder Pressure	588-834KPa@600RPM 85-120PSI@600PSI	-
Cylinder	Cylinder bore diameter	88.00mm, 3.465"	88.17mm, 3.471"
	Warpage		.10mm, .004"
	Valve bushing	6.60mm, .260"	6.75mm, .2657"
	Outside Diameter of piston skirt	87.985mm, 3.464"	87.85mm, 3.459"
	Gap of piston and cylinder	.015-.052mm, .001"	.12mm, .005"
	Inside diameter of piston pin hole	20.002mm, .787"	20.042mm, .789"
	Outside diameter of piston pin	20.00mm, .787"	19.95mm, .785"
	Clearance of piston and piston pin hole	.002-.014mm, .0006"	.08mm, .003"
	Flank clearance of Piston ring	.030-.060mm, .002"	.15mm, .006"
	Closed gap of the first and second ring	.20-.40mm, .012"	1.0mm, .039"
	Closed gap of the oil ring	.20-.70mm, .002"	1.0mm, .039"
	Width of the first ring	2.0mm, .079"	1.75mm, .069"
	Width of the oil ring	2.8mm, .110"	2.7mm, .106"
	Small end diameter	20.005mm, .7876"	20.07mm, .790"
	Large end diameter	36.025mm, 1.418"	36.070mm, 1.420"
	Large end clearance	.040-.066mm, .002"	.12mm, .005"
	Large end flank clearance	.1-.7mm, .019"	1.0mm, .039"
Crankshaft	Crankshaft pin outside diameter	35.985mm, 1.4167"	35.93mm, 1.4146"
	Intake valve adjusted clearance	.15 \pm .02mm, .006 \pm .001"	
	Exhaust valve adjusted clearance	.20 \pm .02mm, .008 \pm .001"	
	Intake valve stem diameter	6.59mm, .259"	6.44mm, .253"
	Exhaust valve stem diameter	6.55mm, .258"	6.40mm, .252"
	Valve guide inside diameter	6.60mm, .260"	6.66mm, .262"
	Clearance of intake valve and guide	.010-.037mm, .001"	.10mm, .004"
	Clearance of exhaust valve and guide	.050-.077mm, .002"	.12mm, .005"
	Valve seat width	1.1mm, .043"	2.0mm, .079"
	Spring free length	39.0mm, 1.535"	37.5mm, 1.476"
	Intake valve cam height	32.44-32.60mm, 1.279"	32.24mm, 1.269"
	Exhaust valve cam height	31.94-32.10mm, 1.260"	31.74mm, 1.249"
	Camshaft collar	15.984mm, .6292"	15.92mm, .6268"
Crankshaft case cover	Camshaft hole	16.0mm, .6299"	16.05mm, .6318"
spark plug	Spark plug gap	0.7-0.8mm, .027-.031"	
spark plug capacity	Resistance	7.5-12.5K ohms	
	Resistance of primary coil	.8-1.0 ohms	
	Resistance of secondary coil	5.9-7.5 ohms	
	Air Gap	.4 \pm .2mm, .016 \pm .007"	

Torque Values

		Torque N/m	Torque in*lb ^f *except where note
Connecting rod bolt	M8X1.25(special bolt)	14	124
Cylinder head bolt	M10X1.25	34	300
Flywheel nut	M16X1.5(special nut)	113	*83 ft*lb ^f
Rocker shaft nut	M6X.5	10	88
Rocker shaft bolt	M8X1.25(special bolt)	24	212
Fuel switch connecting nut	M10X1.25	10	88
Exhaust pipe connecting nut/bolt	M8X1.25	24	212
Air filter bolts	M6X1.0	7.5	66
Air filter nut	M6X1.0	8.5	75
Drain plug	M12X1.25	23	203
Rotor bolt	M10X210	44	389

Standard Torque Values

	M5	5	44
	M6	10	88
	M8	24	212
	M10	37	327
	M12	55	487
	M6	12	106
	M8	26	230
	M10	34	300
	M12	59	522
	M5	4	35
	M6	9	79

Fitting Directions:

1. When fitting the piston in the cylinder the mark “▲” on the piston top must be aimed to the intake valve direction (upper).
2. When fitting the piston rings on the piston the “R,N’ mark on the first and second ring must be upwards, and the gap of all three rings should be 120° apart.
3. The timing marks on the gears must be matched to each other.

Generator Information

Area	Item	Standard	Service Limit
Main Winding	Resistance	.2 ohms	
Field Winding	Resistance	52-62 ohms	
Exciter Winding	Resistance	1.2 ohms	
Main Winding	Resistance	.4 ohms	
Carbon Brush length	Length	.9mm, .354"	5mm, .197"




EPA and Engine Serial Number are located on the panel side of the generator in the location shown.

Chapter 2 Maintenance of the Generator Set


2.1 Maintenance of the Manual Starting System

The integral configuration of the starting device is shown below. Check the condition of the starter. Replace if damaged.



 There is a spring inside the starter device that is under stress. Wear safety goggles and watch for flying debris when it is removed.


Remove the perimeter bolts to remove the starter housing.



Check the condition of the starter system. Replace any broken or damaged parts as follows:



1. Inspect the rope for abrasions. Replace as necessary.
2. Dismantle the starter pawl guide bolt with a socket.
3. Remove the pawls and pawl spring.
4. Visually inspect all parts.




5. Inspect the flute of the starting draw wheel.
6. Remove the shroud from the engine for inspection of the fan blades.
7. Replace parts as necessary.

2.2 Maintenance of the Lubrication System

Choose the oil type according to the local temperature of operation.


Use Four-stroke engine oil. SE, SF or equivalent to SG grade oil (SAE-30). When temp is below 50°F SAE 10W30 is recommended. SAE 5W-30 is recommended when temp is below 5°F.



1. It is best to change the engine oil when the engine is warm. This allows the oil to flow better for a complete drain.
2. Drain the oil from the cylinder block by removing the plug at the base of the engine.
3. Check the condition of the dipstick and o-ring seal.
4. Replace the drain plug.
5. Fill with oil. See specifications in section 1.1 (parameters) for amount to add.

2.3 Maintenance of the Inlet system

1. Remove the air cleaner outer cover by releasing the latches at the top and bottom.
2. Remove the air cleaner element (foam pad). Replace as necessary.



clean the element follow a,b,c,d steps



Never use gasoline, low-burning point solvent, acid or alkaline to clean the element. Use detergent only!

Cleaning the element (foam pad)

Dip the element in the detergent and wring it out. Apply motor oil and wring out excess oil. Install element.

3. Remove the plastic inner housing by removing the six nuts around the perimeter.




4. Remove the enclosure by removing the two nuts inside the enclosure and one on the backside.
5. Remove the carburetor gasket and choke mechanism. Some models may not have automatic chokes and the choke mechanism will not need to be removed. It is built onto the carburetor in this case.
6. Remove the lines to the carburetor and remove the carburetor.




2.4 Maintenance of Fuel System

1. Remove the bowl of the fuel cock.



2. Remove the screen inside the fuel cock.
3. Remove the fuel cock.



4. Pull out the screen inside the tank.
5. Clean or replace both screens and reassemble.

2.5 Maintenance of the Exhaust System


1. Remove the outer heat shield from the muffler.
2. Bend the anti-rotation tabs back around the engine exhaust bolts.
3. Remove the bolts from the engine side of the exhaust pipe.
4. Remove the two bolts from the muffler to the generator head to separate the muffler from the generator.



5. Lift the muffler out of the frame and inspect for cracks.
6. Inspect the spark arrestor mounted over the outlet of the muffler. It should be clear of debris and have no tears in the screen.
7. Replace the muffler or spark arrestor as necessary.



8. Inspect the gasket between the muffler and the engine head.
9. Inspect the engine head for carbon build up. Too much build up in the head or muffler can rob the engine of power.



2.6 Maintenance of the Ignition System

1. Check the gap between the ignition coil and the flywheel. The gap should be $0.4\text{mm} \pm 0.2\text{mm}$, $.016'' \pm .007''$.
2. Check the status of the spark from the ignition coil. It should be a blue spark and must be above 10,000 Volts.




3. When there is no output voltage from the ignition coil, remove the coil by removing the bolts that hold the ignition coil to the engine block.
4. Remove the spark plug cap and unplug the other wires so the ignition coil can be removed.
5. Using a multi-meter capable of measuring resistance or an ohmmeter, connect one end of the tester to the spark plug lead. Connect the other end to the core of the ignition coil. Resistance value of the secondary end of the coil is 2.5K to 2.8K ohms.



6. Connect one end of the ohmmeter to the primary (small black wire) lead, the other end to the core of the ignition coil (same location as before). The resistance value of the primary coil is .25 to .30 ohms.
7. Replace as necessary.



8. Remove the spark plug. Check the cylinder pressure. It should fall in the values noted in section 1.1 of this manual. If the plug is brown in color the engine is working normally.
9. Check for carbon build up on the spark plug. Check the gap of the spark plug. The values for the gap are found in section 1.1 of this manual.
10. Remove the flywheel. Use a screwdriver to hold the flywheel from moving while unloosening the flywheel nut. The torque value of the nut is 113N*m or 83 ft*lb.
11. Remove the flywheel by using a gear puller.
12. Check for any damage to the flywheel. Rust can be removed from the magnet section by light sanding.




2.7 Maintenance of the Generator


1. Remove the two bolts on the rear cover of the generator head.
2. Remove the main bolt in the center of the rotor. Check the bearing.




3. Remove the screws on the outside of the generator head housing.
4. Remove the AVR (large plastic part with wires coming out) Automatic Voltage Regulator.



5. Remove the bolts in the brushes, and remove the brushes.





6. Remove the mounting nuts from the rubber engine and generator head mounts. There are four total, two under the engine and two under the generator head. This will allow you to lift the engine generator combination out of the frame.
7. Remove the rear housing from the generator as shown.
8. Remove the stator cover.



9. Remove the generator stator.

10. Check the stator and rotor for damage or burnt wires. If there are any contact marks or wires that have burnt or the insulation is melted, replace the parts.



11. To remove the rotor from the engine install the bolt that came out of the shaft center. Screw it in until only $\frac{1}{4}$ " is left until the head comes in contact with the bearing.

12. Forcefully strike the screw with a large blacksmith hammer to remove the rotor from the engine.




2.8 Maintenance of the Cylinder Head and Valve


1. Remove the spark plug.
2. Remove the valve cover head bolt located in the center of the valve cover.



3. Check the gasket of the cover. Check the condition of the valve cover gasket.
4. Check the valve clearance of the engine. If they have to be adjusted loosen the valve adjustment nut and then adjust the clearance.
 - a. Clearance for intake $.15\text{mm} \pm .02\text{mm}$, $.006'' \pm .001''$
 - b. Clearance for exhaust valve $.20\text{mm} \pm .02\text{mm}$, $.008'' \pm .001''$.




adjustment nut




tightening nut

5. Tighten the nut with the following torque:
 - c. Adjustment nut 10 N*m, 88 in*lb
 - d. Tightening nut 10 N*m. 88 in*lb
6. Remove the rocker arm for inspection.
7. Remove the lifters and inspect. Rolling them on a flat surface will help to check if they are bent.



rocker arm of valve



8. Remove the rocker arm bolts so you can remove the rocker arm guide plate and inspect the plastic inserts in the plate for damage.
 - e. Torque of the rocker arm bolt is 24N*m, 210 in*lb
9. Inspect the flute and the protruding parts of the rocker arm.
10. Remove the four head bolts. When tightening the 4 head bolts use an across the head sequence.
 - f. Torque of the head bolts is 34N*m, 300 in*lb



11. Remove the head and inspect the head gasket. Sometimes the head may need a tap up with a plastic hammer. Never use a screwdriver between the head and the cylinder or you will damage the surface.
12. Remove the alignment pins.






13. Fill the inlet and exhaust with cleaning fluid from the parts washer and look for leaks around the valves. If there are leaks the valves will need to be lapped and inspected.
14. Clean the carbon deposits off the head. Do not gouge the head surface this will cause a hot spot and melt the head.




Make sure you have on your eye protection.

15. Remove the spring retainer clips from the valve springs. Holding the valve up and using a pair of pliers push down on the retainer. At the same time slide the retainer towards the larger hole and slowly let the retainer up. It should slide off the valve stem.
16. Inspect the valve guide inner diameters. The value for the diameter is listed in section 1.1 tolerance parameters table. Never reuse the guides after they have been pressed out.
17. Inspect the valve seats. Use a vernier caliper to measure the width of the inlet and exhaust valve seat.
 - g. Width of seat: std value 1.1mm up to 2.0mm, .043" to .079"



measure the distortion value of valve stem


18. Inspect the valve spring free height. The values are found in section 1.1 tolerance parameters table.
19. Inspect the valve stem diameter.
20. Measure the distortion value of the valve stem end with a micrometer following the 1 and 2 position in the figure. Replace the valve and valve guide if the distortion value is over the limit of maintenance.
 - h. Inlet valve .12mm, .005"
 - i. Exhaust valve .16mm, .007"




21. Inspect the valve seat area as shown.
 - j. Width of valve end surface 2.0mm, .079" max

2.9 Maintenance of the Crankcase, Crankshaft and Camshaft

1. Make sure all the oil is drained from the crankcase.
2. Remove the flange mounting bolts. See section 1.1 standard torque values.




drain lubricating oil




fixing bolt

3. Remove the crankcase cover. Slight tapping with a plastic hammer may be required. Never use a screwdriver between the cover and the crankcase or you will damage the sealing surface.




crankcase cover




crankcase paper cushion

4. Remove all residue of the gasket. Use a new gasket when reassembling.
5. Inspect the crankcase cover and crank bearing area for cracks or unusual wear. The values for the diameters can be found in section 1.1.
6. Replace the crankcase cover oil seal as necessary.




clean crankcase cover



crankcase cover oil sealing


7. Inspect the crankshaft and camshaft gears. Worn or damaged gears will need to be replaced.
8. Remove the locking pin from the governor shaft.
9. Remove the governor shaft.
10. Note the marks on the gears. They should line up with each other. Remember this for assembly.




lockpin of speed regulating shaft



11. Remove the camshaft.
12. Remove the rod bolts.
 - a. Torque value 14N*m, 125 in*lb



driving gear mark ● timing cam ●




timing cam


13. Remove the connecting rod cap and inspect for damage. See section 1.1 for clearance values.



14. Remove the lifters and inspect.
15. Remove the crankshaft and inspect for damage.



16. Clean the crankcase and inspect for cracks and damage. The diameters can be found in section 1.1.



17. Remove the bolt in the governor gear center and remove the governor gear. Inspect for damage.

18. Inspect the tappet surface for scratches. Both the diameter and the surface the cam rides on.

19. Inspect the cam lobes. Replace the cam if the value is lower than the minimum values.

b. Height for both intake and exhaust minimum is 31.35mm, 1.234"



20. Check the cam journals.

c. Minimum is 15.92mm, .627"

21. Check the MCR (manual compression release). It should be free to move and the spring should easily return it to position.





22. Inspect the crankshaft rod journal.

- d. Diameter should be a minimum of 32.92mm, 1.2960

2.10 Maintenance of the Connecting Rod, Piston and Cylinder

1. Remove the piston from the cylinder. Remove the carbon deposits from the top of the piston.
2. Inspect the inner wall of the cylinder for damage. The values for the diameter can be found in section 1.1 table. Remember to measure the diameter in at least three different locations, for instance, top, middle and bottom.




3. Measure the side clearance of the piston ring with the cylinder with a feeler gauge. This value is shown as the flank clearance in the table in section 1.1.
4. Place the piston rings in the cylinder and measure the gap.
5. With the piston rings removed, put the piston in the cylinder and measure the terminal clearance. Replace the piston or rings as necessary.
6. Remove the piston retaining rings for inspection.



7. Remove the piston pin and inspect.
8. Remove the connecting rod. The limits can be found in section 1.1 table.



9. Measure the piston pin.
10. Inspect the rod end cap.




11. Burnish the piston top with 400 granular sandpaper. Remove the carbon deposits of the piston ring slots with a non-metal tool taking care not to scratch the piston.
12. Measure the outside diameter of the piston pin with a micrometer. The value can be found in section 1.1 table.



13. Check whether the piston rings are scared or the elasticity is weak. Replace as necessary.
14. Measure the piston ring slot. Inspect for abrasion on the piston. Replace if the value is greater than the value found in section 1.1 table.




15. Measure the external diameter of the piston skirt.
16. When installing the piston rings all the gaps should be staggered 120° apart.




2.11 Electrical System

1. Remove the panel of the generator
2. Remove the screws in the plastic panel enclosure.
3. Push in at the clip location, not the screw location, to remove the plastic panel




4. Replace outlets or switches if there is any damage. Replace any wires that may be burnt. Burnt wires are usually from loose terminals.



See trouble shooting section for more information.

2.12 Wiring Diagram



Chapter 3 Defect Analysis and Troubleshooting

3.1 General

3.2 Hard Starting


3.3 Ignition System

Spark Test

WARNING

- 1 Never hold the plug wire when wet.
 - 2 There is no fuel present.
 - 3 Do not test near the plug hole to avoid fire hazards.
-
- 1) Remove the plug and ground the electrode against the engine with the cap attached.
 - 2) Turn on the engine switch and pull the recoil. Spark should jump across the electrodes.

3.4 Generator Power Flow Chart



3.5 Electrical Troubleshooting Stator

12 Volt Battery Test of Stator

Remove the AVR and connect a 12 volt battery to the brush terminals. Make sure the positive and negative terminals are correctly wired. Run the generator at full speed 3750 RPM no load. Follow the chart below:


12 Volt Batter Test for Stator Troubleshooting				
Location	Point Number	Specified Voltage	Voltage Variance	Component Replacement
Main 1	(3) and (4)	59 VAC \pm 5	low	Stator
Main 2	(5) and (6)	59 VAC \pm 5	low	Stator
Exciter	(7) and (8)	56 VAC \pm 3	low	Stator
Sensor	(10) and (11)	8 VAC \pm 1	low/high	Stator
Brushes	(1) and (2)	12 VDC		Battery Problem

It is unlikely but not impossible for all the windings to test low. If all windings test low check the rotor resistance, engine RPM and battery voltage again to make sure these are not the problem.


3.6 General Troubleshooting

Problem	Cause	Correction
	Defective ignition system	Inspect the electrical parts of the ignition system
	Air cleaner is dirty	Clean element
	Air leak from the engine	Check hoses for leaks
	Air leakage from filter	Check filter
	Carbon deposits on spark plug	Clean or replace the plug
	Improper spark plug gap	Check gap
	Spark plug insulator	Replace plug
	Damaged ignition coil	Replace ignition coil
	No spark or light spark of plug	Replace plug
	Plugged fuel filter	Clean filter
	Dirty carburetor	Clean Carburetor
	Air leakage from cylinder head gasket	Replace gasket
	Valve seat leakage	Grind valves
	Valve spring weak	Replace springs
	Valve setting not correct	Set the valve clearance
	Piston and piston rings worn	Replace piston and rings
	Too much carbon on piston and head	Remove carbon
	Crankshaft is damaged	Replace
	Camshaft wear	Replace
	Rocker arm wear	Replace
	Connecting rod wear	Check and replace
	Piston pin wear	Check and replace
	Valve shaft worn	Check and replace
	Valve seat leaking	Check valve and grind if necessary
	Forced cooling fan is broken	Replace fan
	Too low on oil	Change and fill
	Old oil	Change and replace
	Piston oil ring damaged	Replace
	Dirt in the fins	Clean
	Dirt in the shroud	Remove shroud and clean
	Stator interferes with rotor	Replace stator and rotor
	Generator getting hot	Replace bearing
	Cooling fan of generator broken	Replace fan
	Breaker damaged	Inspect and replace
	Load is unstable	Replace AVR
	Voltage is not as stated	Replace AVR
	No voltage	Replace brushes
	Abnormal noise	Replace bearing or tighten center bolt


Chapter 4 Exploded View and Bill of Materials (BOM)



Exploded View of Engine Assembly



Exploded View of Frame Assembly



PPG6000 BOM**8-28-06****Cylinder Head Assembly**

No.	Part No.	Description	Quantity
97	91132-1060-06170B	BOLT, HEAD COVER	1
98	91135-MB-0000	WASHER COMP., HEAD COVER	1
99	11221-MB30-0700	COVER COMP., HEAD	1
100	90229-MB30-0200	PACKING,HEAD COVER	1
101	B057890E10008070B	BOLT, FLANGE, M10X80	4
102	11246-PB52-0000	GUIDE, IN. VALUE	1
103	11247-PB52-0000	GUIDE, EX. VALUE	1
104	11248-MB30-0000	CLIP,VALUE GUIDE	1
105	91138-PB52-0000	BOLT, STUD, M8X34	2
106	81300-KB01-0000	SPARK PLUG NGK BP6ES	1
108	91127-PB52-0000	BOLT, STUD, M8X106	2
109	9022B-QB60-0000	GASKET,CYLINDER HEAD	1
110	91521-12002000000	PIN, DOWEL, 12X20	2
200	11245-PB50-0000	HEAD COMP., CYLINDER	1

Cylinder Barrel

No.	Part No.	Description	Quantity
161	91306-90820817000	WASHER,8.2×17×0.8	1
162	91103-MB30-0000	BOLT, DRAIN PLUG	2
163	91302-91202020000	DRAIN PLUG WASHER	2
165	T1105035005200800	OIL SEAL,35×52×8	1
166	24605-PB52-0000	GOVERNOR ARM SHAFT	1
167	24606-MB30-0000	LOCK PIN	1
168	T1101008001400500	OIL SEAL,8×14×5	1
201	12007-QB60-0100	BARREL ASSY.,CYLINDER	1
202	92102-00000006202	RADIAL BALL BEARING, 6202	1
224	19113-PB50-0000	SHROUD	1
225	B057890006001670B	BOLT M6X16	1

Governor Kit

No.	Part No.	Description	Quantity
149	24620-PB52-0000	GOVERNOR KIT	1
149-1	24626-PB52-0000	GOVERNOR	1
149-2	24621-PB52-0000	GOVERNOR HOLDER	1
149-3	24624-PB52-0000	GOVERNOR WEIGHT	3
149-4	24625-PB52-0000	GOVERNOR WEIGHT PIN	3
149-5	24623-PB52-0000	GOVERNOR HOLDER CLIP	1
149-6	24622-PB52-0000	GOVERNOR SLIDE	1
149-7	B0009601060000K0B	PLAIN WASHER,W6	1

Crankcase Cover			
No.	Part No.	Description	Quantity
141	TD2511-C01-0000	DUCT COVER	1
142	B057890005001270B	BOLT, FLANGE M5X12	3
143	B057890008003570B	BOLT M8X35	7
144	14301-QB62-0300	OIL FILLER CAP	1
145	14303-PB52-0000	O-RING,26×2.7	1
146	12301-PB52-000	CRANKCASE COVER ASSY.	1
147	92102-00000006202	RADIAL BALL BEARING, 6202	1
148	T1105035005200800	OIL SEAL,35×52×8	1
150	92102-00000006207	RADIAL BALL BEARING, 6207	1
151	90208-PB52-0000	CASE COVER PACKING	1
152	91521-08001200000	DOWEL PIN ,8×12	2
Crankshaft Assembly			
No.	Part No.	Description	Quantity
153	13230-PB52-0000	CRANKSHAFT COMP.	1
155	92102-00000006207	RADIAL BALL BEARING, 6207	1
214	13300-PB52-0000	KEY	1
203	91601-MB30-0000	WEIGHT BALANCER	1
Piston Assembly			
No.	Part No.	Description	Quantity
125	1310A-QB62-0000	PISTON RING SET	1
125-1	13103-QB62-0000	FIRST RING SET,PISTON	1
125-2	13104-QB62-0000	SECOND RING SET,PISTON	1
125-3	13108-QB62-0000	THIRD RING SET,PISTON	1
126	13105-PB52-0000	PISTON PIN CLIP	2
127	13101-QB62-0000	PISTON	1
128	13102-PB52-0000	PISTON PIN	1
129	13204-PB52-0000	CONNECTING ROD ASSY.	1
129-1	B057890008003870B	BOLT M8X38	2
Valve Assembly			
No.	Part No.	Description	Quantity
124	15100-QB62-0000	CAMSHAFT ASSY	1
111	15414-MB30-0000	NUT,ARM,VALVE ROCKER	2
112	15403-MB30-0000	PIVOT ADJUSTING NUT	2
113	15401-MB30-0000	ARM,VALVE ROCKER	2
114	15415-MB30-0000	PIVOT BOLT	2
115	15406-MB30-0000	PUSH ROD GUIDE PLATE	1
116	15713-MB30-0000	VALVE ROTATOR	1
117	15711-MB30-0100	IN.VALVE SPRING RETAINER	1
118	15703-MB30-0000	VALVE SPRING	2
119	15701-PB52-0000	EXHAUST VALVE	1
120	15701-PB52-0000	INTAKE VALVE	1
121	15705-MB30-0000	VALVE SPRING SEAT	1
122	15321-PB52-0000	PUSH ROD	2
123	15002-MB30-0000	LIFTER,VALVE	2
211	15712-MB30-0100	EX.VALVE SPRING RETAINER	1
212	1572B-MB30-0000	OIL SEAL	1

Recoil Starter			
No.	Part No.	Description	Quantity
190	21500-PB52-4100	RECOIL STARTER ASSY.	1
190-2	21510-PB50-1100	CASE COMP.RECOIL STARTER	1
190-3	21520-PB52-0000	RECOIL STARTER PULLEY	1
190-4	21512-MB30-0000	STARTER RATCHET	2
190-5	21518-MB30-0000	FRICTION SPRING	1
190-6	21514-MB30-0000	STARTER RETURN SPRING	1
190-7	21515-MB30-0000	RATCHET SPRING	2
190-8	21513-MB30-0000	SPRING RETAINER	1
190-9	21516-MB30-0000	STARTER GRIP	1
190-10	21517-MB30-0000	RECOIL STARTER ROPE	1
190-12	21521-MB30-0000	CENTER SCREW	1
191	B057890006000870B	BOLT M6X8	3
Fan Cover Assembly			
No.	Part No.	Description	Quantity
160	10061-9999-0000	WIRE HARNESS CLIP, 6MM	1
187	21530-PB52-0600	FAN COVER COMP.	1
188	B057890006001270B	BOLT M6X12	6
189	19111-KB03-0000	DRAIN HOLE GROMMET	1
Carburetor Assembly			
No.	Part No.	Description	Quantity
209	17100-QB62-1100	CARBURETOR ASSY	1
Breather Assembly			
No.	Part No.	Description	Quantity
137	17100-QB62-0000	TUBEASSY, 3.5X65	1
138	52609-PB52-0000	WIRE HARNESS CLIP	1
132	17112-QB62-0000	CARBURETOR INSULATOR	1
131	17182-QB60-0000	CARBURETOR PAKING A	1
133	17107-PB50-0000	CARBURETOR PAKING B	1
140	17183-PB52-0000	AIR CLEANER PACKING	2
Flywheel Assembly			
No.	Part No.	Description	Quantity
184	19102-PB52-0000	COOLING FAN	1
185	19102-PB52-0000	STARTER PULLEY	1
183	21520-PB52-0000	COMP. FLYWHEEL	1
186	82150-PB52-0000	NUT,M16	1
Ignition Coil Assembly			
No.	Part No.	Description	Quantity
172	81200-PB52-0600	IGNITION COIL ASSY.	1
171	B057890006002770B	BOLT,M6X27	2

Control Arm Assembly			
No.	Part No.	Description	Quantity
182	24607-PB52-0000	GOVERNOR ARM	1
178	24604-PB52-0000	ROD	1
177	24602-PB52-0000	GOVERNOR SPRING	1
179	24603-MB30-0000	THROTTLE RETURN SPRING	1
176	24610-PB52-0000	CONTROL ASSY	1
176-1	24611-PB52-0000	SHROUD	1
176-2	2461F-PB52-0000	ADJUSTING SPRING	1
180	B061770106000060B	NUT,M6	1
216	B057890006001270B	BOLT,M6X12	3
181	91121-1060-02120B	GOVERNOR ARM BOLT	1
Air Filter Assembly			
No.	Part No.	Description	Quantity
21	12104-MB32-0000	BREATHER TUBE	1
23	16101-MB32-0100	AIR CLEANER ELEMENT	1
24	16106-MB32-0000	AIR CLEANER SEPRATOP (PLASTIC)	1
25	16127-MB32-0000	AIR CLEANER CASE REAR	1
26	TD4121-C01-0000	AIR CLEANER STAY	1
27	16105-MB32-0200	AIR CLEANER COVER CASE FRONT	1
28	16109-MB32-0000	GEMEL	1
30	16102-MB32-0000	AIR CLEANER SEAL	1
33	B061700004000060B	NUT 4MM	6
31	B061770106000060B	NUT,M6	1
34	B061770106000060B	NUT,M6	1
Muffler Assembly			
No.	Part No.	Description	Quantity
35	18000-QC03-0000	MUFFLER COMP	1
36	TD5004-B98-0000	MUFFLER SIDE PROTECTOR	1
37	TD5003-B98-0000	MUFFLER OUTER PROTECTOR COMP.	1
38	TD5002-C03-0000	MUFFLER INNER PROTECTOR COMP.	1
39	TD5006-B98-0000	PROTECTOR MUFFLER SEAL	1
231	18000-QC03-0100	SPARK ARRESTOR	1
230	B057890005002070B	BOLT M5×20	2
40	18100-PB52-0000	EXHAUST PIPE COMP.	1
41	18066-MB32-0100	EX. PIPE GASKET(A)	1
42	18066-MB32-0000	EX. PIPE GASKET (B)	1
43	TD5001-B98-0000	MUFFLER STAY COMP.	1
45	B057890008002570B	BOLT M8×25	2
46	B061700008000060B	NUT 8MM	2
44	B000930008000000B	SPRING WASHER W8	4
241	TD5006-PB50-0000	LOCK PLATE 50mm	1
242	TD500 7 -PB50-0000	LOCK PLATE 60mm	1
47	B057890006001270B	BOLT M6×12	1
48	B057890008001670B	BOLT M8×16	4

Fuel Tank Assembly			
No.	Part No.	Description	Quantity
49	TD6110-B98-0400	TANK COMP. , FUEL	1
217	TD6040-B98-0400	FUEL COCK ASSY.	1
53	TD6140-B93-0000	METER ASSY.,FUEL	1
58	B090740005001000B	SCREW, FLAT, M5×10	2
50	TD6008-B98-0000	FUEL TANK SEAL	1
51	TD6120-B98-0000	FUEL FILLER CAP COMP.	1
218	TD6121-B93-0100	FUEL FILLER CAP PACKING (RUBBER)	1
219	TD6122-B93-0100	FUEL FILLER CAP PACKING (PLASTIC)	1
52	TD6130-B93-0000	FUEL FILTER	1
60	T2999706300130185	FUEL TUBE, W3.5×W10×165	1
59	17020-JC79-0200	TUBE CLIP, (B8)	2
54	B057890006003070B	BOLT, FLANGE, M6×30	4
55	TD6003-B93-0000	TANK CUSHION WASHER	4
56	TD6002-B93-0000	BUSH	4
Control Panel Assembly			
No.	Part No.	Description	Quantity
6	TD2000-C03-2000	CONTROL PANEL ASSY	1
7	TD2006-C03-0100	CONTROL PANEL COMP	1
8	TD9001-C03-0000	CASE,CONTROL PANEL	1
14	B057890006002070B	BOLT , HEX , M6×20	1
16	B061770006000060B	NUT , HEX , M6	2
17	TD2310-C03-0000	CIRCUIT BREAKER 23A	1
18	B000970206000000B	WASHER , PLAIN , W6	1
19	B000930006000000B	WASHER , SPRING , W6	2
20	B057890006002070B	BOLT , M6×20	4
204	TD2410-C03-0100	SOCKET,120V	2
205	TD2410-C03-0200	SOCKET,(120V 240V)	1
206	B06170004000060B	SCREW M4	6
213	TD2016-B92-0000	SWITCH	1
218	TD2611-C03-0000	HARNESS ASSY A., WIRE	1
61	TD2611-C03-0100	HARNESS ASSY B., WIRE	1
219	B000930004000000B	WASHER, SPRING, W4	6
220	B000970204000000B	WASHER, PLAIN, W4	6
221	B061770004000060B	NUT , M4	6
222	TD2018-C03-0100	DIODE ASSY	1
223	B057890006001470B	BOLT , M6×14	1

Frame Assembly			
No.	Part No.	Description	Quantity
63	TD6007-B98-0000	FUEL TANK MOUNTING RUBBER	2
65	TD4111-B98-0000	BOTTOM RUBBER , L	2
66	TD4112-B98-0000	BOTTOM RUBBER , R	2
67	B061770010000060B	NUT M10	4
68	B061770008000060B	NUT M8	4
226	TD4010-C03-1200	WHEEL AND HANDLE ASSY	1
226-1	TD4010-C03-2100	FRAME KIT	1
226-2	TD4013-C03-0200	LEFT GEMEL	1
226-2A	TD4013-C03-0300	RIGHT GEMEL	1
226-3	B057890006004070B	BOLT,M6×40	2
226-4	B000970206000000B	FLAT WASHER,W6	4
226-5	TD4011-C03-0200	HANDLE	1
226-6	B061870006000000B	NUT, M6	2
226-7	TD4015-C03-0400	AXLE OF WHEEL	1
226-8	TD4014-C05-0400	WHEEL	2
226-9	91302-91002030000	FLAT WASHER,W10	2
226-10	B0009300010000000B	WASHER, SPRING, W10	2
226-11	B009230006000000B	NUT,M10	2
226-12	TD4012-C03-0600	FOOT	2
227-13	B094410006001870B	BOLT,M6×18	6
226-14	TD7051-C06-0000	TILE	4
226-15	B057890006005570B	BOLT,M6×40	2
226-16	B057890006003570B	BOLT,M6×35	2
226-17	TD4113-B98-0000	RUBBER BUMPER FOR FOOT	2
226-18	B094410006001870B	M6×18	2
Stator / Housing Assembly			
No.	Part No.	Description	Quantity
70	B057890006001670B	BOLT, FLANGE M6×16	2
71	TD1441-B98-0500	COVER, GENERATOR END	1
72	B057890005001270B	BOLT, FLANGE M5×12	2
73	B061700005000060B	NUT, HEX. ,M5	4
74	B000970205000000B	WASHER, PLAIN, W5	4
76	B000930005000000B	WASHER, SPRING, W5	4
77	TD1461-B98-0000	GROMMET, CRANKCASE	1
78	TD1451-B98-0000	TERMINAL, VOLT CHANGE	1
79	B057890005002070B	BOLT, HEX. , M5×20	2
80	TD1431-C03-0200	REGULATOR ASSY. AUTOMATIC VOLTAGE	1
81	B057890E10026570B	BOLT, FLANGE M5×12	2
82	TD1471-B98-0000	TIE, CABLE	2
83	B057890005001270B	BOLT, FLANGE M 5×12	2
84	B057890006017970B	BOLT, FLANGE M6×125	4
85	TD1421-B98-0000	BRUSH ASSY	1
87	B057890E10026570B	BOLT, FLANGE M5×12	3
88	TD1412-B98-0000	FAN, GENEERTOR COOLING	1
89	B057890005021070B	BOLT-WASHER, M5×210	4
90	TD1411-B98-0000	STATOR/HOUSING ASSY	1
91	B057890010026570B	BOLT, HEX. , M10×265	1
92	B000970210000000B	WASHER, W10×5	1
93	TD1200-C03-0000	ROTOR COMP	1
94	92102-00000006204	BEARING ASSY. , 6204	1
95	TD1100-C03-0000	STATOR ASSY	1
96	TD1110-C03-0000	COVER, STATOR	1
97	TD1210-B98-0000	CLIP,BEARING	1

